

S A R E G A M A
CARVAAN

USER MANUAL



visit www.saregama.com/carvaan/songlist
to download the entire song list

1. Get Started	4
2. Modes	6
3. 80+ Dedicated Stations	9
4. Battery	10
5. Safety Handling	10
6. Warranty Overview	11

Get Started

An overview of the buttons & ports on Carvaan



volume

3.5 mm audio jack for
connecting external
speakers / headphones



charging port

USB port




- Plug the adaptor into an Indian Standard power socket (mains, voltage & frequency at 220V, 50Hz for input and 5V 1A for output)
- Connect the other end of the adaptor to the charging port on Carvaan

Modes

How to use the different modes on Carvaan

To choose a mode, press the corresponding mode button.
The button will light up to indicate that the mode has been activated.



When you power on Carvaan for the first time,
the default mode will be set to Saregama mode.

Saregama mode

In this mode, you can enjoy 5000 ghazals, bollywood songs, the Geetmala Ki Chaon Mein collection by Ameen Sayani and devotional songs from Saregama.

- Press the Saregama mode button
- Press a category button of your choice

Artistes

- 23 music stations dedicated to bollywood legends like Lata Mangeshkar, Kishore Kumar, R. D. Burman and Mohammed Rafi amongst others

Moods

- 9 music stations covering moods like Romance, Happy, Sad and many more

Geetmala

- 50 music stations spanning five decades of the Geetmala Ki Chaon Mein collection by Ameen Sayani

- Turn the station selector left/right to switch to the previous/next music station within a category
- To go to the previous/next song, press the < > buttons

Bluetooth mode

In this mode, you can play songs stored on your personal devices (mobile phone, tablet etc.) through Carvaan speakers.

- Press the Bluetooth mode button
- On your personal device (mobile phone, tablet etc.):

Turn on Bluetooth mode

Select 'Saregama Carvaan' from the list of available Bluetooth devices. Your device will automatically get paired with Carvaan

- Once the devices are paired, the display panel will show 'BT DEVICE PAIRED'



Remember

- Support for Bluetooth version 4.1
- You can only stream music from your phone, laptop or any other supported device to Carvaan. Streaming music from Carvaan to your personal devices like Bluetooth headsets etc. is disabled
- The ◀ ▶ buttons are disabled in this mode

USB mode

In this mode, you can enjoy songs stored on your USB drives on Carvaan.

- Plug your USB drive into the USB port on Carvaan
- Press the USB mode button
- Turn the station selector left/right to move across folders on your USB drive
- To go to the previous/next song, press the ◀ ▶ buttons

Remember

- Support for USB 2.0
- You cannot play songs from your phone/laptop or other devices using a USB connector

FM mode

In this mode, you can listen to local FM radio channels.

- Press the FM mode button. The first available FM channel will automatically start playing
- Press the ◀ ▶ buttons to switch between FM channels or use the station selector to manually tune to a FM channel

Remember

- Only FM radio channels will play in this mode. Other radio channels on AM, SW bands will not work

80+ Dedicated Stations

Moods

1. Romance
2. Sad
3. Happy
4. Ghazal
5. Shakti
6. Spiritual
7. Film Instrumental
8. Sufi
9. Hindustani Classical Instrumental

Geetmala

(Each volume of the Geetmala collection has a dedicated station)

1. Geetmala [1952-1955]
Vol. 1-5
2. Geetmala [1956-1958]
Vol. 1-5
3. Geetmala [1959-1960]
Vol. 1-5
4. Geetmala [1961-1963]
Vol. 1-5
5. Geetmala [1964-1966]
Vol. 1-5
6. Geetmala [1967-1969]
Vol. 1-5
7. Geetmala [1970-1972]
Vol. 1-5
8. Geetmala [1973-1975]
Vol. 1-5
9. Geetmala [1976-1978]
Vol. 1-5
10. Geetmala [1979-2000]
Vol. 1-5

Artistes

1. Lata Mangeskar
2. Kishore Kumar
3. Asha Bhosle
4. Mohammed Rafi
5. Mukesh
6. Hemant Kumar - Geeta Dutt
7. Manna Dey
8. Jagjit Singh
9. Talat Mahmood
10. S.D. Burman
11. R.D. Burman
12. Laxmikant-Pyarelal
13. Kalyanji-Anandji
14. Naushad
15. Shankar-Jaikishan
16. O.P. Nayyar
17. Gulzar
18. Kaifi Azmi - Javed Akhtar
19. Sahir Ludhianvi
20. Anand Bakshi
21. Hasrat Jaipuri
22. Majrooh Sultanpuri
23. Artiste Mix

(Tracks across all Artistes played in random order)

visit www.saregama.com/carvaan/songlist
to download the entire song list

Battery

indicates
battery strength



Battery charge time: 2-3 hours to charge battery fully

Battery usage: Approximately 5 hours once the battery is fully charged

The battery charging indicator (on the back panel of Carvaan) turns red when Carvaan is being charged. This light is automatically turned off when the battery is fully charged.

Safety Handling

1. Care for product

- Keep Carvaan away from heat sources such as heat registers, stoves etc. Excessive heat may damage Carvaan
- Prevent spillage of water or any other liquid as this can cause failure of Carvaan or could prove to be a potential fire hazard
- As a safety precaution, unplug the unit during lightning, storms or when you expect Carvaan will not be used for long durations
- Clean the unit with a dry cloth only
- Please ensure safe handling of Carvaan during transportation

2. Care for battery

- Do not expose the battery to heat sources greater than 60°C
- Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods
- Do not subject the battery pack to a mechanical shock
- In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice
- For prolonging battery life, avoid discharging the battery completely
- Switch off the power button if the battery is completely discharged

3. Care for charger

- Do not use any charger other than that specifically provided along with Carvaan
- If the provided plug does not fit into the requisite power point, consult an electrician
- Do not walk on or pinch the power chord close to the plug

4. Others

- Use attachments/accessories as specified by the manufacturer
- Please contact an authorized service center for any repair/servicing requirements or call the toll free no. 1800-102-7799



Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

Warranty Overview

Page 23 onwards of this manual comprises the warranty card and associated details.

Here's an overview of what the warranty covers:

- 1-year warranty on all parts of Saregama Carvaan. This includes repair, replacement of damaged parts and servicing
- 6-months warranty on the Accessories. This includes repair and replacement of the damaged Accessories

The warranty does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering by the customer
- Functionality of the Product(s) and /or Accessories
- Wear and tear of the memory card, speaker, battery and display panel if the product is used in commercial, business, industrial, educational or rental applications
- Damage caused due to act of god & force majeure events including but not limited to fire or water damage, electrical disturbances etc.

To register a complaint or a service request, please call the toll free no. 1800-102-7799.

India Domestic Service Warranty

1. Definitions

Unless the context otherwise requires, the following terms would have the prescribed meanings:

Accessories: The Adaptor and the USB to micro USB cable provided by Saregama to the Customer along with the Product(s).

Authorised Service Agent: The agents as listed on the website www.saregama.com/carvaan

Saregama: Saregama India Limited, a company having its Office at No.2 Chowringhee Approach, Kolkata- 700072.

Product(s): Saregama Carvaan imported, marketed and sold by Saregama, either directly or through its Authorized Dealers / Authorized Resellers including Authorised Online Resellers. Refer the Authorized Dealers / Authorized Resellers / Authorized Online Resellers list at Saregama Website i.e. www.saregama.com/carvaan ("Website"). Saregama Carvaan purchased out of India is not covered under Product definition and accordingly not eligible for Saregama Warranty.

Customer: An end-user (a person, firm, company or the legal entity) which purchases the Product(s) from Saregama or its Authorized Dealers / Authorized Resellers / Authorized Online Resellers.

Customer Care Centre: Within the territory of India, which collect the Product(s) / Accessories for repair and sends the Product(s) / Accessories for repair to Saregama's Authorised Service Centres through the Authorised Service Agent. Customer to visit the Website for the list of such authorised service centres.

2. Scope of Warranty

Saregama's Warranty for the Product(s) and Accessories is only against any defects in the manufacturer's material or workmanship, which provide for the repair of the defective Product(s) and Accessories. Saregama's warranty does not cover any accidental damage, loss, acts of god, or misuse / abuse of the Product(s) or Accessories or any other event not attributable to the manufacturer's material or workmanship or manufacture of the Product(s) or Accessories.

3. Warranty Period

Product(s) is covered under one year standard warranty from the date of Product(s) purchase by the Customer. Accessories are covered under six months of standard warranty from the date of Product(s) purchase by the customer.

Warranty validation / Warranty period confirmation would be done through Warranty Card and Customer Invoice date.

If a Customer transfers the ownership of Product(s) and Accessories to another person, the remainder of the warranty period may also transfer to the new owner. Customer shall be required to provide proof of purchase including Warranty Card of the Product(s), as a pre-condition for availing the warranty of the Product(s) and/or Accessories.

No claim made by a third party or made by Customer on behalf of a third party shall be entertained by Saregama.

4. Warranty Type

Home Service Warranty: Home service shall be provided at the locations where there is an Authorized Service Centre. Home Service Warranty allows customers to have a technician visit the customer at their home and service the Product(s) and/or Accessories.

Carry-in Warranty: Carry-in Warranty shall be provided at the locations where there is no presence of any Authorized Service Centre in that particular location. Such Carry-in Warranty service requires that the Product(s) and/or Accessories be brought by the Customer to the nearest Authorized Service Center at his/her own cost.

5. Warranty Terms

Warranty is provided only on Product(s) and Accessories which are purchased from Saregama, Saregama Authorized Dealer, Reseller or Authorized Online Resellers. 1-year warranty will be provided on the Product(s). This includes repair, replacement of damaged parts and servicing.

6-months warranty will be provided on the Accessories. This includes repair and replacement of the damaged Accessories.

To register a complaint or a service request, please call the toll free no. mentioned on the warranty card.

The warranty on the Product(s) will be terminated automatically 1 (one) year from the date of purchase of the Product(s) even if the Product(s) were not in use during the warranty period.

The warranty on the Accessories will be terminated automatically 6 (six) months from the date of purchase of the Product(s) even if the Accessories were not in use during the warranty period.

The warranty is limited only to the manufacturing/workmanship defects in the Product(s) and/or Accessories.

There is no warranty on the plastic parts of the Product(s) and/or Accessories.

This Warranty does not cover liability for loss of data/content loaded in the Product(s) due to misuse or tampering by the Customer. If the content is altered, deleted, or in any way modified, Saregama shall not be responsible. Only in case where there is no misuse of the Product or tampering with the data/content and if serviced under warranty, the Product(s) will be returned configured as originally purchased.

The warranty does not cover the replacement of the Product(s) and/or Accessories. Warranty does not cover warranty of functionality of the Product(s) and/or Accessories.

This Warranty does not apply to normal wear and tear to the memory card, speaker, battery and display panel if the Product(s) is used in commercial, business, industrial, educational or rental applications.

Warranty does not cover damage caused due to act of god & force majeure events including but not limited to fire or water damage, electrical disturbances etc.

Within warranty period, Authorised Service Agent will repair or replace any defective part(s) of the Product(s) and/or Accessories if required, to rectify the problem in the Product(s) and/or Accessories. Saregama reserves the right to use re-engineered part(s) with performance parameter equivalent to the similar new part(s)/reconditioned unit, for performing the warranty services.

The replaced part(s) shall become the property of Saregama.

In the event of repairs or replacement of any part(s), during the warranty period, the warranty of the Product(s) or Accessories shall thereafter continue only for the unexpired period of original warranty.

The Warranty of the Product(s) and/or Accessories shall be rendered null and void if:

- The Product(s) and/or Accessories are physically damaged
- The Product(s) and/or Accessories are modified, repaired, maintained and /or opened, disassembled by any party other than the Authorised Service Agent i.e. damage arising out of unauthorized modification, repair, and alteration
- The Product(s) and/or Accessories are operated and/or maintained in ways other than recommended by Saregama in the user manual. Operation of the Product(s) and /or Accessories outside the usage parameters stated in the user manual provided with the Product
- Any malfunction in the Product(s) and/or Accessories resulting from inadequate safekeeping, storage at high temperatures or humidity, storage with mothballs or leakage of batteries
- Any malfunction in the Product(s) and/or Accessories resulting from exposure of the Product(s) and/or Accessories to dirt, sand, water including rust inside the Product(s) and /or Accessories, fire and/or shock
- The model no. or serial no. sticker on the Product(s) and/or Accessories is removed, mutilated or tampered with

- Defect is the result of physical breakage, electric connection or electrical faults external to the Product(s) and/or Accessories
- Any damage occurs to the Product(s) and/or Accessories as a result of Customer's failure to follow the directions in the User Manual
- Any damage to the Product(s) and/or Accessories arising out of use of any consumables or accessories other than those supplied by Saregama, Authorized Dealers, Authorized Resellers or Authorized Online Resellers

6. Limitation of Liability

Saregama makes no other express warranty either in writing or otherwise and expressly disclaims all warranties and conditions not stated in this limited warranty. Saregama does not warrant that the operation of the Product(s) and /or Accessories will be uninterrupted or error-free. To the extent allowed by law, Saregama disclaims all implied warranties or conditions, including any implied warranties or conditions of merchantability, merchantable quality, and fitness for a particular purpose.

Saregama's maximum liability under this limited warranty is limited to the price of the Product(s) and /or Accessories or the cost of repair or replacement charges, whichever is lower.

Except as indicated above, in no event will Saregama be liable for Indirect damage caused due to improper functioning of the Product and / or Accessories, including but not limited to lost profits or savings, business interruption, loss of data, lost revenue, loss of use, or any other commercial or economic loss of any kind, or special, incidental, or consequential damages .

This limitation of liability applies in all circumstances i.e. when damages are sought, a claim made under this limited warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation of liability cannot be waived or modified by any person. This limitation of liability will be effective even if Customer has advised Saregama / its representative of the possibility of any such damages or even if such possibility were reasonably foreseeable.

7. Governing Laws

Any disputes arising in connection with this Limited Warranty shall be governed by the laws of India.

The courts of Kolkata shall have the exclusive jurisdiction over disputes arising hereunder.

For further details contact Saregama's Toll Free No. 1800-102-7799

Warranty is valid only when the Product and /or Accessories are purchased from an authorized dealer and subject to the production of the original proof of purchase.

For online purchases, the invoice received with the Product and /or Accessories will serve as proof of purchase.

WARRANTY CARD

Customer's Name: _____

Customer's Address: _____

Product Serial No: _____

Date of Purchase: _____

Dealer's Name: _____

Dealer's Signature/Seal: _____

I accept the terms and conditions of the warranty

Customer's signature: _____