



RP - Sanjiv Goenka
Group

SAREGAMA
CARVAAN™
— **GO GOLD** —




USER MANUAL

TOP VIEW OF CARVAAN GO GOLD

3.5 mm audio jack for connecting external speakers using Aux cable or to plug in headphones

Power



Power: press for 3 – 4 seconds to power on/off GO Gold; press for a second or less to lock/ unlock GO Gold. If your GO Gold hangs or becomes slower, press for 7-8 seconds to reboot

ACCESSORIES WITH CARVAAN GO GOLD



USB to
Micro USB Cable
Voltage: 220V
Frequency: 50 Hz for
input and 5V 1A for
output



Aux Cable
Connect an Aux
cable to the speaker
to listen to songs
from GO Gold




Earphones



Strapholder

LEFT SIDE VIEW OF CARVAAN GO GOLD



1. SD*: In this mode, enjoy your personal collection of songs stored on your personal micro SD card. SD card mode can also be used as Data Transfer Mode. Here you can transfer your personal collection of song, files etc to and from your Laptop/PC.

2. FM/AM:** Press the mode button to switch between FM & AM. Your earphones act as signal to FM/AM. To use FM (on internal speakers of GO Gold or your own Bluetooth speakers), you will need to plug your earphones into GO Gold

To auto tune FM/AM stations, follow the steps:

Step 1: Press play/pause button for 5 seconds

Step 2: Searching for all FM/AM signals will start. You will hear a searching sound & each FM/AM station will play for approx. 3-4 seconds till all stations are tuned

Step 3: Press next/previous button to go to next/previous station

FM frequency: 87.5 to 108 MHZ

AM frequency: 520 to 1710 KHZ


Note: It is recommended that you do not put the unit on charge while listening to FM/AM as it will interrupt the signal

3. SD SLOT: open the flap to insert your personal micro SD card


** support for micro SD card capacity less than or equal to 32GB*

*** AM station will play as per broadcast timings*


RIGHT SIDE VIEW OF CARVAAN GO GOLD



BOTTOM VIEW OF CARVAAN GO GOLD



FRONT VIEW OF CARVAAN GO GOLD



ARTISTES: 25+ artiste based stations like Lata Mangeshkar, Kishore Kumar & others; this is the default mode on first power on/reset

SPECIALS: 5+ thematic stations like Romance, Ghazal, Sad etc.

PLAYLISTS: 45+ playlists like Yaadein, 80s ka Tadka, Shammi Magic etc.

RESET: Press Artistes & Playlists together for 8 to 10 seconds

SLEEP: If no button is pressed for more than 90 seconds, screen light will turn off. Press any button to activate the screen

SAREGAMA CARVAAN APP



Download the 'Saregama Carvaan' app from the Apple / Android store to enjoy a host of free and subscription based services.

Free services – Use the app to find a song, create playlists to play out on your Carvaan unit.

Note: To use the app, press the 'Artistes / Specials / Playlists' button on Carvaan Go Gold. Connect the app & Carvaan Go Gold using Bluetooth on your phone/tablet.

Subscription services - Subscribe to the app and listen to the songs on your phone/tablet without being connected to the Carvaan Go Gold

Refer to the enclosed insert for steps on how to connect the app and Carvaan Go Gold.

BATTERY

Full battery charge time: Approximately 2 hours

Battery usage: Approximately 7 hours once the battery is fully charged

CONNECTING GO GOLD TO BLUETOOTH SPEAKERS

Step 1: power on your Bluetooth speakers

Step 2: press the Bluetooth mode button for 3 - 4 seconds to turn on Bluetooth on GO Gold

Step 3: turn the dial left/right or press previous/next button to select the speaker

Step 4: press Play/Pause to connect GO Gold to the selected speaker

Step 5: once connection is established, the song plays on the selected Bluetooth speaker

Step 6: to disconnect, press the Bluetooth mode button & press play/pause button on the connected speaker

Step 7: press the Bluetooth mode button for 3-4 seconds to turn off Bluetooth on GO Gold

CONNECTING GO GOLD TO CAR SPEAKERS: Follow all the steps above.

If prompted for a pin / passkey, follow the steps below

1. Press the Bluetooth mode button

2. Use rotary dial and go to 'Change passkey of GO Gold'. Press play/ pause to change the pin / passkey of GO Gold

3. The default passkey of GO Gold is 0000. To change, use rotary dial to change digits from 0-9 and <> to move digits

4. Once all the digits are entered, press play/pause to submit this passkey

5. Follow the steps and reconnect to the car Bluetooth speakers from the list of available devices on GO Gold

Remember: If you turn on Bluetooth on GO Gold, but do not connect or play out for more than 30 minutes, GO Gold will automatically turn off Bluetooth to help conserve battery

SAFETY HANDLING

1. CARE FOR PRODUCT

a. Keep Carvaan Go Gold away from dust and excessive heat (heat registers, stoves etc.)

b. Prevent spillage of water or any other liquid as this can cause failure of Carvaan Go Gold or could prove to be a potential fire hazard

c. Clean the unit with a dry cloth only

d. Do not walk on or pinch the power cord close to the plug

e. Do not immerse Carvaan Go Gold into water

2. CARE FOR BATTERY

a. Do not expose the battery to heat sources greater than 60°C

b. Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods

c. Do not subject the battery pack to a mechanical shock

d. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice

e. For prolonging battery life, avoid discharging the battery completely

3. OTHERS

a. Use attachments / accessories as specified on the box

b. Please contact an authorized service center for any repair/ servicing requirements or call the toll free no. 1800-102-7799



Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

WARRANTY OVERVIEW

Carvaan Go Gold comes with a 6 month Warranty, excluding accessories. This includes servicing/ repair or replacement of damaged parts.

The warranty does not apply and does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering.
- Damage caused due to - force majeure events; events caused by fire, water, electrical disturbances etc., events beyond the control of Saregama; acts of negligence or mishandling, usage for commercial, business, industrial, educational or rental purposes

For any feedback, grievances or suggestions email us at feedback@saregama.com or call us on the toll free no. 1800-102-7799

WARRANTY TYPE

Only Carry-in Warranty is provided. Such Carry-in Warranty service requires that the Product be brought by the Customer, at his/her sole cost and responsibility, to the Authorized Dealers along with the original invoice.

Once the Product is serviced/ repaired/ replaced, the Customer shall be responsible to pick-up the Product from the concerned Authorized Dealer.

IMPORTANT LINKS

Station List & Song List: www.saregama.com/carvaangogold/songlist

Detailed Warranty: www.saregama.com/carvaangogold/warranty

Download 'Saregama Carvaan' App from the Apple/ Android store.

WARRANTY CARD

Customer's Name: _____

Customer's Address: _____

Product Serial No.: _____

Date of Purchase: _____

Expiry Date: _____

I accept the terms and conditions of the warranty.

Retailer's Name: _____

Retailer's Signature/Seal: _____

Customer's Signature