


## USER MANUAL

### TOP VIEW OF CARVAAN GO

3.5 mm audio jack for connecting external speakers using Aux cable or to plug in headphones

Power



**Power:** press for 3 – 4 seconds to power on/off GO; press for a second or less to lock/ unlock GO. If your GO hangs or becomes slower, press for 7-8 seconds to reboot

### ACCESSORIES WITH CARVAAN GO



**USB to  
Micro USB Cable**  
Voltage: 220V  
Frequency: 50 Hz for  
input and 5V 1A for  
output



**Aux Cable**  
Connect an Aux  
cable to the  
speaker to listen to  
songs from GO




**Earphones**



**Strapholder**

## LEFT SIDE VIEW OF CARVAAN GO



**1. SD\*:** In this mode, enjoy your personal collection of songs stored on your personal micro SD card. SD card mode can also be used as Data Transfer Mode. Here you can transfer your personal collection of song, files etc to and from your Laptop/PC.

**2. FM/AM\*\*:** Press the mode button to switch between FM & AM. Your earphones act as signal to FM/AM. To use FM (on internal speakers of GO or your own Bluetooth speakers), you will need to plug your earphones into GO

To auto tune FM/AM stations, follow the steps:

Step 1: Press play/pause button for 5 seconds

Step 2: Searching for all FM/AM signals will start. You will hear a searching sound & each FM/AM station will play for approx. 3-4 seconds till all stations are tuned

Step 3: Press next/previous button to go to next/previous station

FM frequency: 87.5 to 108 MHZ

AM frequency: 520 to 1710 KHZ


*Note: It is recommended that you do not put the unit on charge while listening to FM/AM as it will interrupt the signal*

**3. SD SLOT:** open the flap to insert your personal micro SD card

*\* support for micro SD card capacity less than or equal to 32GB*


*\*\* AM station will play as per broadcast timings*

## RIGHT SIDE VIEW OF CARVAAN GO




*\*\*\*support for BT version 5.0*

## BOTTOM VIEW OF CARVAAN GO



## FRONT VIEW OF CARVAAN GO



**ARTISTES:** 25+ artiste based stations like Lata Mangeshkar, Kishore Kumar & others; this is the default mode on first power on/reset

**SPECIALS:** 5+ thematic stations like Romance, Ghazal, Sad etc.

**PLAYLISTS:** 45+ playlists like Yaadein, 80s ka Tadka, Shammi Magic etc.

**RESET:** Press Artistes & Playlists together for 8 to 10 seconds

**SLEEP:** If no button is pressed for more than 90 seconds, screen light will turn off. Press any button to activate the screen

## SAREGAMA CARVAAN APP



Download the 'Saregama Carvaan' app from the Apple / Android store to enjoy a host of free and subscription based services.

**Free services** – Use the app to find a song, create playlists to play out on your Carvaan unit.

*Note: To use the app, press the 'Saregama mode' button on Carvaan GO. Connect the app & Carvaan GO using Bluetooth on your phone/tablet.*

**Subscription services** - Subscribe to the app and listen to the songs on your phone/tablet without being connected to the Carvaan GO

Refer to the enclosed insert for steps on how to connect the app and Carvaan GO.

## BATTERY

Full battery charge time: Approximately 2 hours

Battery usage: Approximately 7 hours once the battery is fully charged

## CONNECTING GO TO BLUETOOTH SPEAKERS

**Step 1:** power on your Bluetooth speakers

**Step 2:** press the Bluetooth mode button for 3 - 4 seconds to turn on Bluetooth on GO

**Step 3:** turn the dial left/right or press previous/next button to select the speaker

**Step 4:** press Play/Pause to connect GO to the selected speaker

**Step 5:** once connection is established, the song plays on the selected Bluetooth speaker

**Step 6:** to disconnect, press the Bluetooth mode button & press play/pause button on the connected speaker

**Step 7:** press the Bluetooth mode button for 3-4 seconds to turn off Bluetooth on GO

*CONNECTING GO TO CAR SPEAKERS: Follow all the steps above.*

*If prompted for a pin / passkey, follow the steps below*

1. Press the Bluetooth mode button
2. Use rotary dial and go to 'Change passkey of GO'. Press play/ pause to change the pin / passkey of GO
3. The default passkey of GO is 0000. To change, use rotary dial to change digits from 0-9 and <> to move digits
4. Once all the digits are entered, press play/pause to submit this passkey
5. Follow the steps and reconnect to the car Bluetooth speakers from the list of available devices on GO

*Remember: If you turn on Bluetooth on GO, but do not connect or play out for more than 30 minutes, GO will automatically turn off Bluetooth to help conserve battery*

## SAFETY HANDLING

### 1. CARE FOR PRODUCT

- a. Keep Carvaan GO away from dust and excessive heat (heat registers, stoves etc.)
- b. Prevent spillage of water or any other liquid as this can cause failure of Carvaan GO or could prove to be a potential fire hazard
- c. Clean the unit with a dry cloth only
- d. Do not walk on or pinch the power cord close to the plug
- e. Do not immerse Carvaan GO into water

### 2. CARE FOR BATTERY

- a. Do not expose the battery to heat sources greater than 60°C
- b. Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods
- c. Do not subject the battery pack to a mechanical shock

d. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice

- e. For prolonging battery life, avoid discharging the battery completely

### 3. OTHERS

a. Use attachments / accessories as specified on the box

b. Please contact an authorized service center for any repair/ servicing requirements or call the toll free no. 1800-102-7799



Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

## WARRANTY OVERVIEW

Carvaan Go comes with a 6 month Warranty, excluding accessories. This includes servicing/ repair or replacement of damaged parts.

The warranty does not apply and does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering.
- Damage caused due to - force majeure events; events caused by fire, water, electrical disturbances etc., events beyond the control of Saregama; acts of negligence or mishandling, usage for commercial, business, industrial, educational or rental purposes

For any feedback, grievances or suggestions email us at [feedback@saregama.com](mailto:feedback@saregama.com) or call us on the toll free no. 1800-102-7799

## WARRANTY TYPE

Only Carry-in Warranty is provided. Such Carry-in Warranty service requires that the Product be brought by the Customer, at his/her sole cost and responsibility, to the Authorized Dealers along with the original invoice.

Once the Product is serviced/ repaired/ replaced, the Customer shall be responsible to pick-up the Product from the concerned Authorized Dealer.

## IMPORTANT LINKS

**Station List & Song List:** [www.saregama.com/carvaango/go2.0/songlist](http://www.saregama.com/carvaango/go2.0/songlist)

**Detailed Warranty:** [www.saregama.com/carvaango/go2.0/warranty](http://www.saregama.com/carvaango/go2.0/warranty)

Download 'Saregama Carvaan' App from the Apple/Android store.

## WARRANTY CARD

Customer's Name: \_\_\_\_\_

Customer's Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Product Serial No.: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Expiry Date: \_\_\_\_\_

I accept the terms and conditions of the warranty.

Retailer's Name: \_\_\_\_\_

Retailer's Signature/Seal: \_\_\_\_\_

\_\_\_\_\_  
Customer's Signature