

SAREGAMA
CARVAAN
WITH REMOTE

USER MANUAL



visit www.saregama.com/carvaan/songlist
to download the entire song list

1. Overview - Buttons & Ports	3
2. Overview - Remote	5
3. Modes	6
4. 80+ Dedicated Stations	9
5. Battery	10
6. Safety Handling	10
7. Warranty Overview	12

Overview - Buttons & Ports



power

battery charging indicator





- Plug the adaptor into an American Standard power socket (mains, voltage & frequency at 110 - 240 V, 50/60 Hz for input and 5V, 1A for output)
- Connect the other end of the adaptor to the charging port on Carvaan

Overview - Remote

Choose your preferred category when in Saregama mode




To replace the remote control battery:

- Open the battery compartment
- Insert a fresh CR2025 battery with the correct polarity (+/-)
- Close the battery compartment
- Discard the used battery

Modes

To choose a mode, press the corresponding mode button on Carvaan/remote.
The button will light up to indicate that the mode has been activated.



When you power on Carvaan for the first time,
the default mode will be set to Saregama mode.

Saregama mode

In this mode, you can enjoy over 5000 ghazals, bollywood songs, the Geetmala Ki Chaon Mein collection by Ameen Sayani and devotional songs from Saregama.

- Press Saregama mode on Carvaan/remote
- Press a category button of your choice on Carvaan/remote

Artistes

- 24 music stations dedicated to bollywood legends like Lata Mangeshkar, Kishore Kumar, R. D. Burman and Mohammed Rafi amongst others

Moods

- 9 music stations covering moods like Romance, Happy, Sad and many more

Geetmala

- 50 music stations spanning five decades of the Geetmala Ki Chaon Mein collection by Ameen Sayani
- To go to the previous/next music station within a category, turn the station selector left/right on Carvaan or press < > on the remote
- To go to the previous/next song, press the < > buttons on Carvaan/remote

Bluetooth mode

In this mode, you can play songs stored on your personal devices (mobile phone, tablet etc.) through Carvaan speakers.

- Press Bluetooth mode on Carvaan/remote
- On your personal device (mobile phone, tablet etc.):

Turn on Bluetooth mode

Select 'Saregama Carvaan' from the list of available Bluetooth devices. Your device will automatically get paired with Carvaan

- Once the devices are paired, the display panel will show 'BT DEVICE PAIRED'



Remember

- Support for Bluetooth version 4.1
- You can only stream music from your phone, laptop or any other supported device to Carvaan. Streaming music from Carvaan to your personal devices like Bluetooth headsets etc. is disabled
- You can use only your personal device to play/pause or go to the previous/next song

USB mode

In this mode, you can enjoy songs stored on your USB drives on Carvaan.

- Plug your USB drive into the USB port on Carvaan
- Press USB mode on Carvaan/remote
- To move across folders on your USB drive, turn the station selector left/right on Carvaan or press < > on the remote
- To go to the previous/next song, press the I< >I buttons on Carvaan/remote

Remember

- Support for USB 2.0
- You cannot play songs from your phone/laptop or other devices using a USB connector

FM mode

In this mode, you can listen to local FM radio channels.

- Press FM mode on Carvaan/remote. The first available FM channel will automatically start playing
- Press I< >I buttons on Carvaan/remote to switch between FM Channels; you can also use the station selector on Carvaan to manually tune to a FM channel

Remember

- Only FM radio channels will play in this mode. Other radio channels on AM, SW bands will not work

80+ Dedicated Stations

Moods

1. Romance
2. Sad
3. Happy
4. Ghazal
5. Shakti
6. Spiritual
7. Film Instrumental
8. Sufi
9. Hindustani Classical Instrumental

Geetmala

(Each volume of the Geetmala collection has a dedicated station)

1. Geetmala [1952-1955]
Vol. 1-5
2. Geetmala [1956-1958]
Vol. 1-5
3. Geetmala [1959-1960]
Vol. 1-5
4. Geetmala [1961-1963]
Vol. 1-5
5. Geetmala [1964-1966]
Vol. 1-5
6. Geetmala [1967-1969]
Vol. 1-5
7. Geetmala [1970-1972]
Vol. 1-5
8. Geetmala [1973-1975]
Vol. 1-5
9. Geetmala [1976-1978]
Vol. 1-5
10. Geetmala [1979-2000]
Vol. 1-5

Artistes

1. Lata Mangeshkar
2. Kishore Kumar
3. Asha Bhosle
4. Mohammed Rafi
5. Mukesh
6. Hemant Kumar - Geeta Dutt
7. Manna Dey
8. Jagjit Singh
9. Talat Mahmood
10. S.D. Burman
11. R.D. Burman
12. Laxmikant-Pyarelal
13. Kalyanji-Anandji
14. Naushad
15. Shankar-Jaikishan
16. O.P. Nayyar
17. Gulzar
18. Madan Mohan
19. Kaifi Azmi - Javed Akhtar
20. Sahir Ludhianvi
21. Anand Bakshi
22. Majrooh Sultanpuri
23. Top 300
24. Artiste Mix

(Tracks across all Artistes played in random order)

visit www.saregama.com/carvaan/songlist
to download the entire song list

Battery

indicates
battery strength



Battery charge time: 2-3 hours to charge battery fully

Battery usage: Approximately 5 hours once the battery is fully charged

The battery charging indicator turns red when Carvaan is being charged. This light is automatically turned off when the battery is fully charged.

Safety Handling

1. Care for product

- Keep Carvaan away from heat sources such as heat registers, stoves etc. Excessive heat may damage Carvaan
- Prevent spillage of water or any other liquid as this can cause failure of Carvaan or could prove to be a potential fire hazard
- As a safety precaution, unplug the unit during lightning, storms or when you expect Carvaan will not be used for long durations
- Clean the unit with a dry cloth only
- Please ensure safe handling of Carvaan during transportation

2. Care for battery

- Do not expose the battery to heat sources greater than 60°C
- Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods
- Do not subject the battery pack to a mechanical shock
- In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice
- For prolonging battery life, avoid discharging the battery completely
- Switch off the power button if the battery is completely discharged

3. Care for charger

- a. Do not use any charger other than that specifically provided along with Carvaan
- b. If the provided plug does not fit into the requisite power point, consult an electrician
- c. Do not walk on or pinch the power chord close to the plug

4. Care for remote

- a. Do not expose the remote to extreme temperatures or high humidity
- b. Do not immerse it in water
- c. Remove the battery when the remote is not in use for long periods of time
- d. Do not mix different brands or types of batteries in the remote

5. Others

- a. Use attachments/accessories as specified by the manufacturer
- b. To register a complaint or a service request, please send an email to help@saregama.com



The FCC Declaration of Conformity or the FCC label or the FCC mark is a certification mark employed on electronic products manufactured or sold in the United States which certifies that the electromagnetic interference from the device is under limits approved by the Federal Communications Commission. A device that is marketed for use in the home or a residential area by the customer comes under Class B devices which require either Verification, Certification, or Self Declaration depending on the type of product. Saregama Carvaan comes under Class-B and it undergoes all the requirements generated by FCC and has received the FCC certificate after going a Declaration of Conformity under the new FCC Doc/Self declaration procedures.



The European Directive on the Restriction of Hazardous Substances (RoHS) holds electrical and electronic equipment companies directly responsible for the chemical compliance of their products. This means all products must conform to strict standards, provide extensive compliance documentation, and ensure that electrical and electronic products sold in the USA do not contain lead, cadmium, mercury, hexavalent chromium, polybrominated biphenyls (PBBs), and polybrominated diphenyl ethers (PBDEs) above the legal threshold. Manufacturers, owners, retailers, and importers alike need to ensure that their

products comply in order to be distributed and sold in the USA.

The equipment (Saregama Carvaan) has been tested and found to comply with the limits of the following hazardous substance in the product as per RoHs guidelines.

- Lead (Pb): < 1000 ppm
- Mercury (Hg): < 100 ppm
- Cadmium (Cd): < 100 ppm
- Hexavalent Chromium: (Cr VI) < 1000 ppm
- Polybrominated Biphenyls (PBB): < 1000 ppm
- Polybrominated Diphenyl Ethers (PBDE): < 1000 ppm
- Bis (2-Ethylhexyl) phthalate (DEHP): < 1000 ppm
- Benzyl butyl phthalate (BBP): < 1000 ppm
- Dibutyl phthalate (DBP): < 1000 ppm
- Diisobutyl phthalate (DIBP): < 1000 ppm



WEEE stands for Waste from Electrical and Electronic Equipment. WEEE Directive 2002/96/EC mandates the treatment, recovery and recycling of electric and electronic equipment. Saregama Carvaan being sold in the USA market had passed all the WEEE compliance and carry the "Wheeler Bin" sticker on the label as well. Saregama has labelled its branded electronic products with the WEEE Symbol to alert our customers that their products bearing this label should not be disposed in a landfill or with municipal or household waste.

Warranty Overview

Page 13 onwards of this manual comprises the warranty card and associated details.

Here's an overview of what the warranty covers:

- 1-year warranty on all parts of Saregama Carvaan (excluding accessories). This includes repair, replacement of damaged parts and servicing

The warranty does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering by the customer
- Functionality of the Product(s)
- Wear and tear of the memory card, speaker, battery and display panel if the product is used in commercial, business, industrial, educational or rental applications
- Damage caused due to act of God & force majeure events including but not limited to fire or water damage, electrical disturbances etc.

To register a complaint or a service request, please send an email to help@saregama.com

U.S.A. Domestic Service Warranty

1. Definitions

Unless the context otherwise requires, the following terms would have the prescribed meanings:

Accessories: The Remote, Adaptor and the micro USB cable provided by Saregama to the Customer along with the Product(s).

Saregama: Saregama Inc., a corporation incorporated in the state of Delaware, United States of America, and having its office at 200 Continental Drive, Suite 401, Newark, Delaware 19713 USA

Product(s): Saregama Carvaan imported, marketed and sold by Saregama, through its Authorized Dealers / Authorized Resellers including Authorized Online Resellers. Saregama Carvaan purchased outside of U.S.A. is not covered under Product definition and accordingly not eligible for Saregama Warranty. Product does not include Accessories.

Customer: An end-user (a person, firm, company or the legal entity) which purchases the Product(s) from Saregama or its Authorized Dealers / Authorized Resellers / Authorized Online Resellers.

2. Scope of Warranty

Saregama's Warranty for the Product(s) is only against any defects in the manufacturer's material or workmanship. Saregama's warranty does not cover any accidental damage, loss, acts of God, or misuse / abuse of the Product(s) or any other event not attributable to the manufacturer's material or workmanship or manufacture of the Product(s). Accessories are not covered under warranty.

3. Warranty Period

Product(s) is covered under 1-year standard warranty from the date of Product(s) purchase by the Customer. Warranty validation / Warranty period confirmation would be done through Customer Invoice date. If a Customer transfers the ownership of Product(s) to another person, the remainder of the warranty period may also transfer to the new owner. Customer shall be required to provide proof of purchase of the Product(s), as a pre-condition for availing the warranty of the Product(s). No claim made by a third party or made by Customer on behalf of a third party shall be entertained by Saregama.

4. Warranty Type

Any unit of the Product(s) identified with a manufacturing defect will be replaced with a new unit of the Product(s) by Saregama.

5. Warranty Terms

Warranty is provided only on Product(s) which is purchased from Saregama, Saregama Authorized Dealer, Authorized Reseller or Authorized Online Resellers. 1-year warranty will be provided on the Product(s).

In order to claim the Warranty Customer will have mail their request to help@saregama.com

The Customer will receive as reply to his/ her email an address on which said Customer may send the defective unit of the Product ("said address"). The defective unit of the Product and Accessories must be sent to the said address (with the original packaging when purchased or similar packaging) at the cost of the Customer. Once the said defective unit of the Product and Accessories is received at the said address, Saregama will dispatch a fresh unit of the Product and Accessories to Customer's address. In the event on receipt, Saregama finds that the allegedly defective unit of Product does not have any defects, Saregama will dispatch the same unit of the Product and Accessories received from Customer, back to the Customer's address.

In order to avail the Warranty, Customer will have to provide the invoice of the unit of the Product purchased by Customer to Saregama, either by dispatching it to Saregama along with the defective unit of the product or by emailing to Saregama at the email address provided for the same purpose a scanned copy of the said invoice.

The replaced unit of the Product and Accessories shall become the property of Saregama.

This Warranty does not cover liability for loss/content loaded in the Product(s) due to misuse or tampering by the Customer. If the content is altered, deleted, or in any way modified, Saregama shall not be responsible.

Warranty does not cover warranty of functionality of the Product(s).

This Warranty does not apply to normal wear and tear to the memory card, speaker, battery and display panel if the Product(s) is used in commercial, business, industrial, educational or for rental purpose.

Warranty does not cover damage caused due to act of God and force majeure events including but not limited to fire or water damage, electrical disturbances etc.

The warranty on the Product(s) will be terminated automatically 1 (one) year from the date of purchase of the Product(s) even if the Product(s) was not in

use during the warranty period. The warranty is limited only to the manufacturing/workmanship defects in the Product(s). There is no warranty on the plastic parts of the Product(s) and on Accessories.

The Warranty of the Product(s) shall be rendered null and void if:

- The Product(s) is physically damaged
- The Product(s) is modified, repaired, maintained and /or opened, disassembled i.e. damage arising out of unauthorized modification, repair, and alteration

The Product(s) is operated in ways other than recommended by Saregama in the user manual. Operation of the Product(s) outside the usage parameters stated in the user manual provided with the Product

- Any malfunction in the Product(s) resulting from inadequate safekeeping, storage at high temperatures or humidity, storage with mothballs or leakage of batteries
- Any malfunction in the Product(s) resulting from exposure of the Product(s) to dirt, sand, water including rust inside the Product(s), fire and/or shock
- The model no. or serial no. sticker on the Product(s) is removed, mutilated or tampered with
- Defect is the result of physical breakage, electric connection or electrical faults external to the Product(s)
- Any damage occurs to the Product(s) as a result of Customer's failure to follow the directions in the User Manual
- Any damage to the Product(s) arising out of use of any consumables or accessories other than those supplied by Saregama, Authorized Dealers, Authorized Resellers or Authorized Online Resellers

6. Limitation of Liability

Saregama makes no other express warranty either in writing or otherwise and expressly disclaims all warranties and conditions not stated in this limited warranty. Saregama does not warrant that the operation of the Product(s) will be uninterrupted or error-free. To the extent allowed by law, Saregama disclaims all implied warranties or conditions, including any implied warranties or conditions of merchantability, merchantable quality, and fitness for a particular purpose. Saregama's maximum liability under this limited warranty is limited to the price of the Product(s) or replacement charges, whichever is lower. Except as indicated above, in no event will Saregama be liable for Indirect damage caused due to improper functioning of the Product, including but not limited to lost profits or savings, business interruption, loss

of data, lost revenue, loss of use, or any other commercial or economic loss of any kind, or special, incidental, or consequential damages. This limitation of liability applies in all circumstances i.e. when damages are sought, a claim made under this limited warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation of liability cannot be waived or modified by any person. This limitation of liability will be effective even if Customer has advised Saregama / its representative of the possibility of any such damages or even if such possibility were reasonably foreseeable.

7. Governing Laws

Any unit of the Product(s) identified with a manufacturing defect will be replaced with a new unit of the Product(s) by Saregama.

Any disputes arising in connection with this Limited Warranty shall be governed by the laws of Delaware, U.S.A. The courts of Delaware, U.S.A. shall have the exclusive jurisdiction over disputes arising hereunder.

Warranty is valid only when the Product is purchased from an authorized dealer and subject to the production of the original proof of purchase. The invoice received with the Product will serve as proof of purchase.

Customer's Name: _____

Customer's Address: _____

Product Serial No: _____

Date of Purchase: _____

Dealer's Name: _____

Dealer's Signature/Seal: _____

I accept the terms and conditions of the warranty

Customer's Signature: _____